



Sette 270W Feet and Shim

1. Install the soft feet on the 4 front locations
2. Install the soft foot on the 5th location at the back of the grinder, with one 0.25mm shim between the foot and bottom of the grinder (see below)

