



Forté Touch Screen Troubleshooting

-Error Code Legend-

“LLLL” Indicates a damaged load cell->Replace load cell

“HHHH” Indicates bad load cell *** If unit flashes “HHHH” then immediately switches to “LLLL”, you have a bad faceplate -> Replace the faceplate.

“EEEE” Indicates that a weight greater than the 300g max is on the load cell- try not to exceed this weight or you risk damage to the scale.

-Faceplate Removal-

1. Move both adjustment knobs to the finest positions (1-A).
2. Position the grinder upside down.
3. Remove the center Phillips screw that secures the faceplate.



4. Insert the calibration tool into the adjustment arm slot to help pry the faceplate away from the grinder.



5. Use side cutters to **gently** grab the Molex connector, rocking it back and forth while pulling to remove. Unplug both Molex connectors.



If you have any questions or concerns, please email support@baratza.com or call at 425-641-1245.